



Nelson & Nelson Mfg.
2200 Fowler Ave, Suite D
Jonesboro AR 72401
870-268-6393 : Cell 219-1019

Installation Instructions 3-5-19

Model RYK-SBL
RYKER Sway Bar Links

Steps needed to install your Sway Bar Links



See Authorized Dealers for installation if needed.

- 1.- Remove left & right side factory Sway Bar Links by removing two bolts on each link.
- 2.- Take the new Sway Bar Links with spacers each side on bottom of link only and hold in place with the 6mm set screw.



Install the link bottom first. Take the factory bolt and run through the frame channel hole through the spacers / bearing holes. This will push the set alignment screw through the other side. This will set the link in place to install the factory nut. Tighten down the nut back to its position from the factory. Then install the upper bolt. A spacer will go between the sway bar and the bearing as well as a spacer on the outside. Install the bolt and tighten.
Do the same for the other side and your new links are installed.

We thank you for purchasing one of our Ryker Sway bar links. We know today the need for accessories that provide a higher level of comfort while riding and we have solved that demand with a stylish system that compliments the design of your Ryker®!

spyderextras.com