



**Nelson & Nelson Mfg.**  
5210 Stadium Blvd, Suite C  
Jonesboro AR 72404  
870-268-6393 : Cell 219-1019

Installation Instructions 2-12-20

**Model RYK-SBK**  
**Ryker Sway Bar Kit.**

**Steps needed to install your Sway Bar & Links**



**We recommend using an Authorized Dealer for installation of this Sway Bar Kit.**

This Kit installation is based on removing the existing sway bar and links, removing mounting bolts to radiator and then lifting upwards out of the way then replacing with this new Bar, Links and Bushings.

- 1.- This installation requires advanced technical knowledge of your Ryker as one would receive from your local dealers. If you have those skills and know your Ryker, swapping this kit, replacing the factory will be easy as removing the old and replacing with this new kit.
  - 2.- This installation requires that the front grill assembly be completely removed exposing the radiator. Then the Radiator must be disconnected from the base amount and lifted upwards out of the way exposing access to the existing factory bar kit.
  - 3.- Dealership or a trained technical person knowing the Ryker can continue with the installation from here removing the factory kit and installing this new kit. Install the bushings in the same manner as removing the factory. Use the factory bolts to install the new bushings.  
( Spyder Extras Sway Bar Links Purchased Separately )
  - 4.- Remove left & right-side factory Sway Bar Links by removing two bolts on each link.
  - 5.- Take the new Sway Bar Links with spacers each side on bottom of link only and hold in place with the 6mm set screw.
  - 6.- Install the link bottom first. Take the supplied new bolts and run through the frame channel hole through the spacers / bearing holes. This will push the set alignment screw through the other side. This will set the link in place to install the factory nut. Tighten down the nut back to its position from the factory. Then install the upper bolt. A spacer will go between the sway bar and the bearing as well as a spacer on the outside. Install the bolt and tighten.  
Do the same for the other side and your new links are installed.
- 4.- This Sway Bar kit provides better handling than the factory upgrade Red Sway Bar by over 200 pounds more in tensile strength.

We thank you for purchasing one of our Ryker Sway Bar Kits. We know today the need for accessories that provide a higher level of comfort while riding and we have solved that demand with a stylish system that compliments the design of your Ryker!

[Spyderextras.com](http://Spyderextras.com)