



Nelson & Nelson Mfg.
5210 Stadium Blvd, Suite C
Jonesboro AR 72404
870-268-6393 : Cell 219-1019

Installation Instructions 2-28-21

Model SPY-PRSK

Steps needed to install your Passenger Seat Backrest Risers.



1.- Remove the existing arm rest by removing the two screws holding the armrest to the main arm mount. You will see two sets of holes in the mount once the armrest is removed. Take the armrest riser as shown below and the two screws you removed and mount the new riser plate in the top upper holes in the mount.



2.-Next take the new screws, washers and nuts and install the armrest back on the new riser mount just like it was mounted to the existing mount. The screw goes in the armrest bracket first then once the screw is in slot add the washer and locknut to the outside. Do not tighten down at this point. Add the other screw as the first. Then before tightening down adjust the armrest forward or backwards to the desired position.

We thank you for purchasing one of our Spyder Accessories. Today we know the needs for accessories for your Spyder and we have solved that demand with a stylish system that compliments the design of your Spyder®!