



Nelson & Nelson Mfg.
5210 Stadium Blvd, Suite C
Jonesboro AR 72404
870-268-6393 : Cell 219-1019

Installation Instructions 2-27-23

Model SPX-HCR
BRP TRAILER HITCH COVER

Steps needed to install your Hitch Cover.



- 1.- Clean the top of the Hitch with the supplied accelerator alcohol pads from sides to hitch area. First lay the cover over the hitch and verify the placement. The wider upper portion of the cover should be on the left side.
- 2.- Next remove the tape from the adhesive back. Place over the hitch with the wider part of the cover on the left. It aligns perfectly with the outside of the hitch. Press down in place.
- 3.- Use the supplied wire cable clamps as shown below to run your trailer hitch wiring to your Spyder. Your new cover is now in place. This will help block any road dirt etc. from your trailer.



We thank you for purchasing our Trailer Hitch Cover. Today we know the needs for accessories that provide a higher level of comfort while riding and we have solved that demand with a stylish system that compliments the design of your Spyder®!