



Nelson & Nelson Mfg.
5210 Stadium Blvd, Suite C
Jonesboro AR 72404
870-268-6393 : Cell 219-1019

Installation Instructions 8-1-22

Model SF3-SBRK

Spyder F3T & Limited Saddle Bag Racks

Steps needed to install your Saddle Bag Racks



- 1.- Take the Left Template as shown below and lay it over the top of the saddle bag. Note the arrows to align the template with the shape of the top of the saddle bag. Take Painters tape as an example and tape down areas shown below to hold the template in place. Take an 1/8" drill bit and drill a small pilot hole in the center of each drill hole location on the template.



2.- Next take a 5/16" drill bit and drill out all 3 holes using the 1/8" hole as a guide. This hole is a little larger than the bolt to allow movement and alignment.

3.-Take the left Rack and the small cylinder spacer and with the bolt through the rack back corner hole put the spacer on the opposite side of the rack. Then take the tapered spacer and do the same for the other two holes. Once the rack has all 3 bolts and spacers located underneath then align with the holes in the saddle bag tip and place the rack in place. Take the washer and locknut per bolt and tighten each down evenly. Too, tighten just enough to compress the tapered rubber spacer so that it seals tight around the top of the saddle bag. Not a set amount of tightness just enough to compress the tapered spacer and seal against the top of the saddle bag. The back rear cylinder shape spacer, do the same. You can tweak all 3 to obtain best fit. Do the same for the right side.



Right Side Rack Shown

Left Side Rack Shown

We thank you for purchasing one Spyder Accessories. Today we know the need for accessories and we have solved that demand with a stylish system that compliments the design of your Spyder!

spyderextras.com