



Nelson & Nelson Mfg.
5210 Stadium Blvd, Suite C
Jonesboro AR 72401
870-268-6393 : Cell 870-219-1019

Installation Instructions 10-21-25

Model CAN-GRL
Canyon Grille Guard

Steps needed to install your Canyon Front Grille Guard



- 1.- To Install your new Canyon Grille Guard first take a T-30 wrench and remove the factory bolts and accent covers as shown below.



2.- Next the supplied new accent covers as both are the same for each side and take the plastic spacer as shown below and place it on the back side. Take the 4 supplied bolts & washers and install them through the accent covers. The alignment of the bolts will be pointing downward when properly aligned as the bolts screw into the frame at a slight angle. The plastic spacer has alignment stubs that align with the larger hole in the metal guard for proper alignment. Do this for the opposite side. Once both sides are in place you are ready to install the guard. On the lower photos you can see from the right side the angle of the bolts being screwed into place.



**3.-Tighten down the 4 bolts using a 5mm Allen wrench. Tighten each down evenly using a cross pattern to do so.
Once all are tightened down your new Grille Guard is installed!**



We thank you for purchasing our Canyon Front grille Guards. Today we know the need for Quality Accessories, and we have solved that demand with a stylish system that compliments the design of your NEW CANYON®!

spyderextras.com