



Nelson & Nelson Mfg.
5210 Stadium Blvd, Suite C
Jonesboro AR 72401
870-268-6393 : Cell 870-219-1019

Installation Instructions 10-23-25

Model SPX-BTCP
2024+ RT Bluetooth CarPlay Switch

Steps needed to install your 2024+ Bluetooth CarPlay Switch



1.- To Install the Bluetooth CarPlay Activation Switch you need to plug this device in a spare USB socket on your Spyder. It cannot be the USB in your glove box that your phone will use. It normally is best in the trunk or other USB outlet to obtain its power. Once plugged in, go to your screen and connect to a device and choose the "Headset Device."

Look for a device labeled T7

Connect to that device and this will set the system to the ON position internally as a headset setting required to activate the CarPlay. It may take a few minutes to pair.

Then plug your phone into the USB plug in the glove box using a data power cable not just a power cable. Spyder Extras has cables just for the CarPlay for the iPhone and Android phones.

Your Phones CarPlay should immediately show up on your screen!

We thank you for purchasing our Spyder Accessories. Today we know the need for quality Accessories, and we have solved that demand with a stylish system that compliments the design of your Spyder®!

spyderextras.com