

Nelson & Nelson Mfg. 5210 Stadium Blvd, Suite C Jonesboro AR 72404 870-268-6393: Cell 219-1019

Installation Instructions 4-22-24

Model RYK-RCK

Ryker Rear Carrying Rack

Steps needed to install your Ryker Carrying Rack



1.- You must have installed the BRP Max Mount to mount this Ryker Carrying Rack. If the Max Mount is installed the rear small rubber trim must be removed

The additional mounting holes with black caps will be used on future accessories.

2.- Take Blue Loctite and apply to the threads on the 4 supplied 6MM bolts. Under the end of the Max Mount, you will see 4 mounting holes.

If you normally carry heavier objects, you can use the two 6mm bolts on the front of the mount and use the suppled button head 1/4-20x1-1/4" bolts on the rear. Using these bolts then washers and locknuts on the rear mounts require you drill a 1/4" hole through where the max mount is threaded on the two rear mounts. This will provide a more secure carrying load capacity with the rear bolts not pulling the threads out due to weight.

3.-You will see 2 sets of slots that allow the rack to be placed where the rack is closer to the passenger seat or further away. Decide which position best fits your needs.

Place the Carrying Rack under the Max Mount and secure to the Max Mount with the 4 bolts. The Carrying rack mounting holes have slots so you have adjustment if needed.

Tighten down all bolts and do not overtighten. If you want the rack placed towards the driver the 2nd set of slots from the front is used to place the front two bolts. That will leave the front two slots empty no bolts. Then the rear two bolts will align with the rear slots. The Max Mount is Aluminum which is softer metal as not to strip out the threads on the mount.

Once installed you are complete.



Rack shown in the #2, back slot position allowing the rack closer to passenger.